



# Mystic Lighting

---

## Warnings & Disclaimers:

\*FOR OUTDOOR USE ONLY.

\*Professional installation recommended.

\*Only for use with low-voltage landscape lighting systems that provide equipment grounding.

\*Use a minimum of 18AWG/2C wire, rated for direct burial of less than 6".

\*To avoid risk of electrical shock, do not connect your trunk line into your transformer until all light fixtures have been installed.

\*Don't place light fixtures near flammable materials.

\*Light fixtures should be installed a safe distance from any fountain, spa/hot tub, swimming pool, or other large body of water.

\*Light fixtures must be hung on a structure capable of supporting the weight of the fixture plus the additional stress of any possible wind.

\*Don't power a light fixture if it contains any parts that are missing or broken.

\*Don't submerge in water.

\*Product contains glass, and improper care or handling can result in potential serious injury and/or damage to product.

\*Don't over tighten set screws into glass globe.

---

**Step 1:**

Drive post into the ground to preferred depth and skip to Step 3. For hanging fixture, begin at step 2.



**Step 2:**

Hang fixture from desired structure and secure glass-housing assembly and wire to the structure at intervals of every 2-3 feet downward.



**Step 3:**

Cut trunk line and strip 5/8" of insulation from each wire. Trim wiring from light fixture, making sure to leave sufficient excess to facilitate the wire connection and burial. When finished, you will have six individual wires with 5/8" of exposed copper, two coming from the light fixture, two coming from the transformer, and two leading to the next light fixture in the sequence.



**Step 4:**

Line up one wire coming from the fixture, one wire coming from the transformer, and one wire leading to the next fixture in your sequence and twist together using the provided silicon-filled wire nuts. Repeat with remaining three wires. This provides a watertight seal and is rated for direct burial.



**Step 5:**

Install bi-pin LED bulb by aligning pins with receptacle slots and pressing gently until bottomed out.



**Step 6:**

Attach colored glass to the base and tighten slotted setscrews. **RISK OF GLASS BREAKAGE, DO NOT OVER TIGHTEN SET SCREWS.** Hand-tight is sufficient for most applications.



REPEAT STEPS 1-6 FOR REMAINING FIXTURES IN YOUR SEQUENCE, THE FINAL FIXTURE WILL BE CONNECTED DIRECTLY WITH THE END OF THE TRUNK LINE.